





1

Arm Rest




Raise or lower arms to help support forearms and to keep shoulders aligned in a neutral position.

Press button to move arm rest up and down.

2

Arm Width




Adjust the width of the arms based on personal preference and body size. Keep them as close to the torso as possible for maximum support.

Press lever back horizontally to unlock arm and adjust width.

3

Seat Height




Adjust the seat height to find the optimal seated position. Legs should be at ninety degrees for the best support.

Pull lever up to adjust seat height.

4

Seat Glide




The seat slides forward and back to a position that best supports the leg length and reduces pressure, providing long-term comfort.

Pull lever up to adjust the seat glide.

7

Lumbar Support




Adjust the lumbar support to best fit the user. The lumbar provides proper support to the lower back.

Slide up or down for desirable comfort.

5

Tilt Tension




Proper tension should allow you to lean back easily while providing support when reclining.

Turn knob forward or backward to adjust the tilt tension.

6

Tilt Lock



Back can be locked in an upright position or set to recline freely.

Pull lever in and out for tilt lock.